



## Pneumatic Quick Coupling Computer No

Each product has been given a fixed number to identify every different product.

Example: CA Type Small Flow Quick Coupler A0135CAJA-20SFN.

### A0135CAJA - 20SFN

The first number "A" represent quick coupler

The eleventh number

Type of thread				
Sign	/	N	S	G
Meaning	PT	NPT	BSP	UNF

The tenth number

Type of connection					
Sign	F	M	H	P	C
Meaning	Female thread	Male thread	Hose	Lock tube	Labor saving

The ninth number

Socket		
Sign	S	P
Meaning	Socket	Plug

The eighth number

Size									
Sign	10	15	20	25	30	40	400	600	800
Meaning	1/8"	3/16"	1/4"	5/16"	3/8"	1/2"	1/2"	3/4"	1"

The seventh number

Nationality		
Sign	JA	MA
Meaning	Japanese Standard	European Standard

The sixth number

Type of coupler			
Sign	CA Type	AA Type	MA Type

The fifth number

Spring						
Sign	1	2	3	4	5	6
Meaning	Steel Dye Black	Steel Plated Argon	Steel Plated Nickel	Brass	SUS 304	SUS 403

The fourth number

Steel Ball								
Sign	1	2	3	4	5	6	7	0
Meaning	Steel	SUS 403	SUS 304	SUS 316	Brass	Iron	SUS 420	Meaningless

The third number

Seal									
Sign	1	2	3	4	5	6	7	8	9
Meaning	NBR	HNBR	VITON	SI	Teflon	PU	CR	EPDM	High temp

The second number

Body										
Sign	0	1	2	3	4	5	6	7	8	9
Meaning	Brass	Steel	SUS 304	Zn	Al	Plastic	Teflon	Carbon alloy	Carbon steel	SUS 420



## Mold Quick Coupling Computer No

Each product has been given a fixed number to identify every different product.

Example: MK Type Quick Coupler A0135MKJA-20SFN.

### A0135MKJA - 20SFN - 50L

The first number "A" represent quick coupler

The twelfth number

Custom length (Ex: 50mm length = 50L)	
Sign	L

The eleventh number

Type of thread					
Sign	N	S	AT	G	
Meaning	PT	NPT	BSP	UNC	UNF

The tenth number

Type of connection					
Sign	F	M	H	HL	P
Meaning	Female thread	Male thread	Hose	Elbow hose	Lock tube

The ninth number

Socket		
Sign	S	P
Meaning	Socket	Plug

The eighth number

Size						
Sign	10	15	20	25	30	40
Meaning	1/8"	3/16"	1/4"	5/16"	3/8"	1/2"

The seventh number

Nationality		
Sign	JA	DA
Meaning	Japanese Standard	Germany Standard

The sixth number

Type of coupler			
Sign	MDA Type	WA Type	MK Type

The fifth number

Spring						
Sign	1	2	3	4	5	6
Meaning	Steel Dye Black	Steel Plated Argon	Steel Plated Nickel	Brass	SUS 304	SUS 403

The fourth number

Steel Ball								
Sign	1	2	3	4	5	6	7	0
Meaning	Steel	SUS 403	SUS 304	SUS 316	Brass	Iron	SUS 420	Meaningless

The third number

Seal									
Sign	1	2	3	4	5	6	7	8	9
Meaning	NBR	HNBR	VITON	SI	Teflon	PU	CR	EPDM	High temp

The second number

Body										
Sign	0	1	2	3	4	5	6	7	8	9
Meaning	Brass	Steel	SUS 304	Zn	Al	Plastic	Teflon	Carbon alloy	Carbon steel	SUS 420




## Car Wash Machine Quick Coupling Computer No

Each product has been given a fixed number to identify every different product.

Example: TS Type Quick Coupler A0175TSJA-02SFN.

### A0175TSJA - 02SFN





## Hydraulic Quick Coupling Computer No

Each product has been given a fixed number to identify every different product.

Example: DA Type Quick Coupler A0325DAJA-02SFN.

### A0325DAJA - 02SFN

